




Silnik kosy spalinowej Grass VM431 1E40F-5E (43cc)

The Parts List of Model 1E40F-5E GASOLINE ENGINE



NR	OPIS (ENG)	NUMER CZĘŚCI
1	Starter	1E44F-5E.3
2	Handle Plug	1E44F-5E.3-1
3	Start Handle	1E44F-5E.3-2
4	Start Cover Case	1E44F-5E.3.1
5	Recoil Spring	1E44F-5E.3-3
6	Rope	1E44F-5E.3-4
7	Start Pulley A	1E44F-5E.3-5
8	Spring	1E44F-5E.3-6
9	Start Pulley B	1E44F-5E.3-7
10	Washer	1E44F-5E.3-8
11	Screw	1E44F-5E.3-9
12	Bolt M5X25	GB70+GB93+GB97.1
14	Claw	1E36F-2C.5-3A
15	Spring	1 E36F-2C.5-2A
16	Stop Ring 4	GB/T896
17	Start Ratchet Ass'y	1E36F-2C.5A
18	Seal	1 E36F.2
19	Crank Case	TU52-1

20	Gasket	1E40F-5.8-4
21	Bearing 6202/P5	GB/T276
22	Crank Shaft	1E40F-5.4.1
23	Key 3X13	GB/T1099
24	Pin B5X12	GB/T119
26	Crank Case	TU52-2
29	Seal	1E40F-5.9
30	Screw M5X30	GB70+GB93+GB97.1
31	Magneto Rotor Comp.	1E40F-5.3
32	Nut MS	GB/T6177.1
33	Coil	T43.1
34	Bolt M5X20	GB70+GB93+GB97.1
35	Earth Wires Comp.	1E44F-5E.5
36	Washer B	1E36F-3
37	Spring	1E40F-5.6-1
38	Clutch Ass'y	1E40F-5.6.1
39	Washer	1E40F-5-11
40	Step Screw	1 E40F-5-12
41	Bolt M5X20	GB70+GB93+GB97.1
42	Fan Cover	1E44F-5E-5
44	Bearing	1E40F-5.4-2
45	Piston Circle Clip	1E40F-03.02.01
46	Piston	1E40F-5.4-1
47	Piston Pin	1E46FP.6-3
48	Bolt M5X12	GB/T9074.4
49	Piston Ring	1E40FP-3Z.3-5
50	Gasket	1E40F-5-6
51	Cylinder	1E40F-5-4B
52	Screw M5X20	GB70+GB93+GB97.1
53	Screw M4X8	GB/T9074.4
54	Cylinder Cover	1 E44F-5E-3
55	Screw M5X8	GB/T818
56		
57	Heat Shield Gasket	1E44F-5E.2
58	Muffler	1E44F-E.1
59	Muffler Cover	1E44F-E-2
60	Screw M6X55	GB70+GB93+GB97.1
61	Spark Plug	L6
62	Spring	T43-5
63	Cap	1E44F-5E-4
64	Gasket	1E40F-5-2
65	Inlet Pipe	1E40F-5A.2
66	Bolt M5X25	GB70+GB93+GB97.1
67	Gasket	1E40F-5A-1

68	Carburetor	1E40F-5E.6
69	Filter Body	1 E36F-5E.1.1
70		
71		
72	Screw M5X55	GB70+GB93+GB97.1
73	Air Filter	1 E36F-5E.1-1
74	Filter Cover	1E44F-5E-2A
75	Screw	1E44F-5E.1
76	Fuel Tank	1 E44F-5E-6
77	Stand	1E44F-5E-7
78		
79		
80	Lid Ass'y	1E32FL.6.2
81	Chain	1 E32FL.6.2-4
82	Fuel Pipe (out)	EB-415.4.2-4
83	Plug	1 E36FF.8.1-1
84	Fuel Pipe (in)	CG420.1.3.2-2
85	Fuel Filter	1 E34F.9.2-3
86	Fuel Pipe Ass'y	1 E44F-5E.4